

٠,




Figure 3A

▼ Select Existing Config

Monitor Data

Override Set Clock

Holidays

Temp SetPts Upload Config New Config

T7350 Configuration Tool

Version: 0.0.d.18d

Figure 4B

Back Next Save SaveAs

Figure 3B

Control: Standard Heat Pmp

Cnfg ID: 00

DownLd

Model: • Mod1_Basic

120 character description which is

user entered.

Config Name: New Config

Description:

Figure 4D

(i) Please connect PDA serial port to the 17350

using serial cable.

OK) Cancel


Configuration Tool

Version: 0.0.d.5

Summary Config Name: New Config Description:	Connecting to 17350 Please connect PDA serial port to the 17350 using serial cable.	Fígure 5C	n figuraj R 0.04.18	Set Clock Holidays Temp SetPts (Wkly Schedule) Upload Config New Config Select Existing Config
T7350 Configuration Tool	Set Clock Holidays Temp SetPts (Wkly Schedule) Upload Config New Config	Figure 5A	Sunarnary Select Setup Config Name: New Config Description: 120 character description which is user entered.	Model: • Mod1_Basic Control: Standard Heat Pmp Cnfg ID: 00 DownLd Back (Next) (Save (SaveRs)

Select Setup Back Next Save SaveBsControl: Standard Heat Pmp Description: Customer XYZ summary. information. Model: ▼ Mod1_Basic Config Name: XYZ Cnfg ID: 00 Summary DownLd

Figure 6A



OK) (Cancel

Conf Download Conf Upload Desc Monitor
120.0 Set Clock R
Calibrate

Model Control

Config Name: XYZ


Description:

XYZ configuration.

Figure 8A

Figure 7A

Down Load Next



Temp SetPts Upload Config New Config

Override Set Clock

Dehumid Hot Gas BP Simple Dehumid

Economizer

Time of Day


AuxDO:

Figure 9C

Figure 9A

Figure $8 {
m L}$

Back (Next



Remote

Occ Sensor: None

Rel Humidity: Room

Local

Remote Rmt+5tP Remote

RoomTemp:

Figure 9B

Figure 9D


r Data	SubBaselD: T7350D,3H3C,RH FirmwareVersion: 0.0.19	RoomTemperature: 79.2F EffectiveSetPoint: 75.0F	RoomRH: 31% Dehumidification: Off	DischargeRir Temp: 70.3 F	-
Monitor Data	SubBaselD: FirmwareV	RoomTemperatur EffectiveSetPoint:	RoomRH: Dehumidification:	Discharge	


Discharge RirTemp: None Remote


Outdoor None


Rir Temp:
Back Next


Figure 8E























Delays: ManualMode:

¥3: ▼ OFF

G: ▼ OFF

Close

¥1: ▼ OF **Y2:** ▼ OFF

800 Manual OFF.

8

8

Override

ManualMode: Delays:

Y1: ▼ OF ¥2: ▼ OF

¥3: ▼ OFF

G: ▼ OFF

Figure 14Z

Figure 14 χ

Manual Override




Figure 15






Figure 16








Figure 19





Figure 20A






Figure 21







Figure 22




25/33









28/33




Figure 26




Figure 27

9

	Commission Summary	Sensors
17350 Configuration Tool	Sensors: Failed	Valid
Version: diag1	Fan/Rux: UnTested	RoomTemp: 73F
ر ر	Cooling: OK	Remote SetPt: -5
J.	Heating: OK Frror Summaru:	Remote Bypass: Off
Set Clock Commission	DISCHARGE AIR SENSOR FAILURE:	Testing Room Temp
_ ,	Temperature sensor is configured and is out of range or disconnected.	Room Temp: 73F
Upload Config Wkly Schedule	SENSO TE OLITOO SENSOB	Temperature.
New Config J	Rock (Next) (Core)	Pass Fail
▼ Select Existing Config	DOLL JUST JUST	
Fígure 28A	Fígure 28C	Fígure 29B
<i>C</i>	n O))
	Sensors	Sensors
17350 Configuration 1001	Palid	PiloA
Version: diag1	RoomTemp: 73F	RoomTemp: 73F
17350 Online Diggostics	Remote SetPt: -5	Remote SatPt: -5
	Remote Bypass: OFF	Testing Remote SetPt
(i) Please connect PDH serial part to the 17350	Room Rel Humidity: 55 %	(?) Remote SetPt:-1
using the serial cable &	Occupancy Sensor: OFF	Please rotate remote setpoint to the full -
Themostat Interface	Discharge Rir Temp: Failed	position (CCW) and tap
	Outdoor Rir Temp: 60 F	OK.
	(Back)(Next)(Update)(Test)	¥
()		

Fígure 29C

Figure 29A

Figure 28B

ManualMode: OF Fan Status: OF Valid Clg Stage1 - Y1: OF □	(?) Fan Status: ON	Please confirm Fan operation.	Pass Fail

of Stages: 1 DischargeAirT: 78F CoilDeltaT: 0F

Progress: [[......

Cancel

Testing Cooling Stages

Figure 31C




Figure 31D

Coo	Cooling Equipment	
_	ManualMode: OFF	
	Fan Status: Off Ya	Valid
<u>5</u>	Clg Stage1 - Y1: OF	
ď	Cla Stage 2 - V2 - Off	ď
	l esting cooling stages	Г
	Validated Stage 1	
	Cooling Operation Progress:	:
	Cancel	

Valid V

ManualMode: OF Fan Status: OF Clg Stage1 - Y1 : OF

Cooling Equipment

Figure 31G

Figure 31E

Cooling Equipment
Fan Status: OF Valid
Clg Stage1 - Y1: OF S
Clg Stage2 - Y2: OFF ☑
Clg Stage3 - Y3: OF S
Back) (Next) (Update) Test

Cancel

Testing Cooling Stages

Clg Stage1 - Y1: OFF

ManualMode: OFF

Cooling Equipment

Fan Status: OFF

Fígure 31F

Figure 31H

Figure 32E

Back Next Update Test

Heating Equipment	ManualMode: OFF Fan Status: OFF Valid	Testing Heating Stages	(?) Htg Stage 1: OFF	Please confirm it is safe	Stage contact.	Yes No

를 □

Htg Stage1 - W1: OF Fan Status: OFF ManualMode: OFF

Heating Equipment

Htg Stage1 - W1: OF

ManualMode: OFF Fan Status: OFF

Heating Equipment

Figure 32C

(Back) (Next) (Update) (Test

Figure 32A




Figure 32B

g J

Yes)[

Figure 32D

Veile Testing Heating Operation Please confirm fan air flow is required for stage 1 heating.

Fan Status: OFF

ManualMode: OFF Fan Status: OFF

Heating Equipment




Figure 33